PIONEER®
The Art of Entertainment

Service Manual

ORDER NO.
CRT 1445

REMOTE CONTROLLER UNIT

CD-R55 E

SCHEMATIC CIRCUIT DIAGRAM



S1: BSM S6 : + SOURSE
S2 :TUNER S7 : LAN
S3 : CD S8 : ATT
S4 : BAND S9 : - VOLUME
S5 : - SOURSE SI0 : + VOLUME

Decimal points for resistor and capacitor fixed values are expressed as :
2.2 → 2R2
0.022 → R022

Fig.1

PIONEER ELECTRONIC CORPORATION 4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan
PIONEER ELECTRONICS SERVICE INC. P.O. Box 1760, Long Beach, California 90801 U.S.A.
PIONEER ELECTRONICS OF CANADA, INC. 505 Cochrane Drive, Markham, Ontario L3R 8E3 Canada
PIONEER ELECTRONIC [EUROPE] N.V. Keetberglaan 1, 9120 Beveren, Belgium
PIONEER ELECTRONICS AUSTRALIA PTY. LTD. 178-184 Boundary Road, Braeside, Victoria 3195, Australia TEL: [03] 580-9911
© PIONEER ELECTRONIC CORPORATION 1991
FM DEC. 1991 Printed in Japan

PARTS LIST

*** : Non Spare Part**

Mark	No.	Description	Part No.
*	1	Remote Control Assy	CXA4659
	2	Battery Cover	CNS2197



Fig. 2

Mark	No.	Description	Part No.
*		Owner's Manual	CRD1565
		Fastener	CNM3249
		Fastener	CNM3250

Owner's Manual

Part No.	Language
CRD1565	English, French, German, Spanish, Italian